




Brockway Model 154WH

TRACTOR CHART



MODEL 154WH TRACTOR												
W.B.	A	B	C	D	E	F	G	H	K	L	M	S
153	69		103		34	222 1/2	71 1/8	95 5/8	47 3/4	13 1/8	5 3/4	10.00-22
							71 1/8	95 5/8	47 3/4	13 1/8	5 3/4	10.00-20
							71 1/8	96	46 1/2	13 3/4	5 3/4	11.00-20

BROCKWAY MOTOR COMPANY, INC.
 GENERAL OFFICE AND FACTORY
 CORTLAND, NEW YORK